


Manufacturer of No-Dig Pipe Repair Products

Installation Tips Link-Pipe SewerSealer™ VD (with Grout)








Recommended Grout:

Link-Pipe Inc. recommends that G-200 Grout is used with Link-Pipe Sewer SealerTM for structural repair. The G-200 grout reacts with water and forms a dense rigid foam, which creates an excellent structural capability with the Sewer SealerTM.

Grout Application:

All Grout supplied with the sleeve must be used. Grout should be stored in a dry and cool place at all times. Pour the Grout slowly onto the gasket. Use a paint roller (provided in the package) to work the Grout into the gasket. The area of the gasket under the "flap" (The so-called "flap" is the top loose foam sheet not glued to the sleeve) must be filled first, after which the rubber bands are applied to keep the flap in place. The rest of the gasket is then filled with the remaining Grout.

Grout must be applied <u>evenly</u> (Use the diagram below for technique in creating an even application). The Grout is easily absorbed and could leave some part of the gasket empty if it is not carefully and evenly spread. This may cause a failure in sealing.



LINK-PIPE and are registered trademarks of Link-Pipe Inc. in Canada. LINK-PIPE is a registered trademark and is a trademark of Link-Pipe Inc. in the United States. Dia-Meter, Gas Sealer, Hydro-Seal, Insta-Line, Grouting Sleeve, Link-Pipe PVC, Pressure-Seal, Sewer Sealer, and Sewer Sealer VD, eresure-Seal, Insta-Line, Grouting Sleeve, Link-Pipe PVC, Pressure-Seal, Sewer Sealer, Hydro-Seal, Insta-Line, Grouting Sleeve, Link-Pipe PVC, Canadian Patent No. 2,131,291, Hong Kong Patent No. HK1003143. Gas Sealer, is protected by US Patent No. 6,138,718. Jacketed Sealer, is protected by US Patent No. 9,052,051, Russian Patent No. 2533604, Chinese Patent No. ZL201010153141.9, Hong Kong Patent No. HK1149066.


Manufacturer of No-Dig Pipe Repair Products

Warning:

Water must be poured onto the grout before the sleeve is inserted into the pipe. The Grout starts reacting within 18 to 20 minutes after coming into contact with water. If the sleeve is not installed within 18 to 20 minutes after the reaction with water, the grout may already be in the final stage of curing. Therefore, no time should be wasted after the Grout is put into contact with water. **The sooner the sleeve is installed, the thinner the grout mixture is, the easier the installation will be and better sealing.**

Installation:

- 1. Apply the grout to the sleeve (see **Grout Application** above).
- 2. Insert the plug into the sleeve and center the sleeve on the plug.
- 3. Orient the sleeve on the plug so that the label is up (at 12 o'clock of the crown of the sleeve).
- 4. Carefully inflate the plug just enough to keep the sleeve from moving on the plug while traveling in the pipe. *If too much pressure is applied, the sleeve may open prematurely or if the pressure drops, the sleeve may slip.* Both could result in lost control when the assembly is being transported in the sewer.
- 5. Before inserting the plug-sleeve assembly into the sewer, the sleeve should be wetted with cool water, so that the entire surface of the Grout-filled gasket is wet.
- 6. Pull the plug-sleeve assembly to the repair site. For the purpose of keeping good control over the installation process, the installer must monitor the accuracy of locating the plug-sleeve assembly over the intended repair site. It is always helpful to accurately predetermine the distance from pipe entrance at the Manhole to the damaged area, and mark the camera cable for later easy reference.
- 7. For continuous (series) installation, overlap 3" to 4" of the small-flared end (with label "This side overlaps installed sleeve") over the installed sleeve (Pic.1).



LINK-PIPE and are registered trademarks of Link-Pipe Inc. in Canada. LINK-PIPE is a registered trademark and is a trademark of Link-Pipe Inc. in the United States. Dia-Meter, Gas Sealer, Hydro-Seal, Insta-Liner, Grouting Sleeve, Link-Pipe PVC, Pressure-Seal, Sewer Sealer, and Sewer Sealer VD, are trademarks of Link-Pipe Inc. Grouting Sleeve, is protected by US Patent No. 5,351,720, Canadian Patent No. 2,131,291, Hong Kong Patent No. HK1003143. Gas Sealer, is protected by US Patent No. 6,138,718. Jacketed Sealer, is protected by US Patent No. 9,052,051, Russian Patent No. 2533604, Chinese Patent No. ZL201010153141.9, Hong Kong Patent No. HK1149066.

27 West Beaver Creek Rd., Unit # 2, Richmond Hill, Ontario Canada L4B 1M8 Tel: (905) 886-0335 Fax: (905) 886-7323 E-Mail: info@linkpipe.com http://www.linkpipe.com

Manufacturer of No-Dig Pipe Repair Products

- 8. To install the sleeve, bring the air pressure to about 15-20psi above "Calibration pressure". (Note: Calibration pressure of a Link-Pipe Plug is the pressure required to expand the plug up to the host pipe diameter in free air).
- 9. Release the air pressure and, with the camera, check to see whether all the locks are engaged in a single row, if not, insert the plug again, move the plug to the small end of the sleeve and apply 5 psi more pressure and repeat the installation.

As already stated, the sleeve should be fully installed within 20 minutes from wetting. More time is rarely needed. It has been noticed that water in the sewer does not affect the Grout if the timing is observed. However, once the installation pressure is applied, the reaction of the Grout speeds up very quickly. The installation should be finished without delay.

It is not a problem if water backs up during the installation and the camera is obstructed. Simply apply the prescribed pressure with an added 5-psi and do it all within the 20 minutes of allocated time.

If you feel not comfortable with this instruction, CONTACT LINK-PIPE BEFORE INSTALLATION. For more information, please call Lembit (Lem) Maimets or Danny Gan at 1-800-265-5696.